

DimaMat

Post installation guide



Once installed the DimaMat system requires 24 hours to become fully load bearing

DO's

The system can be used as working surface if the following precautions are observed.

Site traffic thoroughfares should be protected with 1 x 18mm ply. Sweep before laying ply!

Entire system should be protected with 1 x 18mm for regular, normal site foot traffic

Ladders to be used on 1 x 18mm ply after 48 hours

Towers and scaffolding to be erected on 1 x 18mm ply after 48 hours

The heating system can be turned on after 48 hours – no heating protocol required

DO NOT's

Pallet trucks of ANY kind should NOT be used directly on the system

DO NOT apply heavy / point loads at the edge of the system

DO NOT allow scissor lifts, cherry pickers

DO NOT proceed with final floor installation on damaged areas

DO NOT allow any foot traffic on the system before the 24-hour cure time