






System PIPE – Preparation and connection




It is imperative that the Jupiter multi pipe is cut straight.



Once cut, the pipe end must be prepared by using the 16mm Jupiter pipe beveling tool.





Twist until pipe meets the end of the tool and the pipe is neatly bevelled.




Drill bit versions can be used for larger projects



Visually check to ensure that the pipe is bevelled as per diagram right.



If using Jupiter press fittings to connect pipe together, ensure pipe is pressed fully in and the Jupiter pipe can be seen in the viewing window.



Insert the pipe and connector into the Jupiter Hand press tool jaws and depress handle fully either side of the white collars. Release handle fully to remove pipe. White collars can be removed after connecting.